


PARTS LIST
DC 9630



No.	Description	Part No.
1	Headpad	15977P-04
2	Earseal (pair)	15976P-03
3	Microphone M-2H 5 OHM	09168P-75
4	Screen, Wind, Mic	40062G-06

No.	Description	Part No.
5	Windscreen Cover w/Tie	18792G-03
6	Mic Protector/Windscreen Kit	41090G-20
7	Volume Control Knob Assy	40585G-02

DC 9630

Usage Instructions

The suspension system on the DC 9630 is designed for a simple and comfortable fit. Proper fit is necessary for maximum effectiveness. The headset should be worn so that the headpad lightly touches the top of the head. Adjust the sliding assembly on each side as necessary, keeping slide positions equal on either side. For proper microphone placement, adjust boom up/down and in/out by rotating and flexing the boom as necessary. Ideal microphone placement is 1/8" from the lips as this will provide maximum intelligibility and ambient noise rejection.

Replaceable Parts Removal/Installation

- M-2H Microphone (09168P-75) and mic protector (40062G-06)
 - To remove: Gently pull off foam cover. Grasp microphone firmly and pull straight out.
 - To install: Align keyway on microphone with keyway on boom. "TALK" should be inward towards the user's face. Push until microphone snaps into place.

- Earseals (15976P-03)
 - To remove: Gently pull off.
 - To install: Stretch earseal over lip on dome until completely seated on dome.

- Headpad (15977P-04)
 - To remove: Gently pull off.
 - To install: Align headpad with headband assembly and push all around the perimeter to engage hook-and-loop fasteners.